




# Whirley Gig





Round and even  
stick 10-20cm




Small cuts the same  
way up




7-15cm long



Make holes for the stick.  
Assemble. Bind the sticks if  
needed.



Cut 1.5m of string.  
Send through the slots and tie to the stick.



Make each  
length the  
same and  
tie at the  
top to  
make a  
loop.  
Hang away  
from a  
wall. Wind  
up and let  
it run.